

Cut - Glue - Caulk - Paint = Enjoy your beautiful home!

Installing your StyroTrim® accents is easy and fast.

Cut: Using a standard wood saw or power saw, cut through the outer exterior finish of your trim to the desired lengths. Miter (diagonal) cut the corners when needed.

Glue: Glue trims to wall using a low solvent exterior construction adhesive. A generous S-curved bead of clear 100% silicone works well. In some instances, use double stick foam tape on back of trim to hold it to the wall while the adhesive cures. Also, strips of masking tape across the outside surface of the trim will hold in place until the adhesive dries. On heavier installations, a nail or screw can be driven into the wall first with the accents attached to keep it in place.

Caulk: Before painting, fill any seams or gaps with stucco patch or our exclusive "StyroCaulk®", stucco caulking.

Paint: Paint the accents with the color or finish of your choice.

Cutting Window Sill Returns from 8' stock trim*

* If you purchased stock sills with finished end returns, please disregard these instructions.

Please follow these instructions to achieve a finished return to your wall on each side of the window.

Lay sill flat-side down. At one end of your sill, measure the return depth on the flat side of the sill stick and transfer it to the sill face (R). Cut two miters (an "upside down" V) in the sill with the point of the V at the place you marked. Each cut must be 45 degrees as shown. By doing this, you will cut two pieces from the sill.

The middle piece (X) will be discarded and the end piece (with the most finished surface) becomes the return to the wall when flipped (as shown). Repeat procedure for return on other side of sill.



Lowes.StyroTrim.com